


# UX-GN9V/GN7V/GN6/GN5

## Motion Sensor

The touch panel illuminations turn on with an approaching hand.



## Laser Touch Operation

Skip songs or adjust the volume by sliding your finger along the illumination strip on the right side of the unit.

